



Samba Service

- **Samba** is an open-source software service on Unix/Linux systems.
- Designed for **files** and **printer** sharing for Windows and/or Linux clients (with a graphical interface).
- Samba replaces the Windows server, based on SMB (Server Message Block) for resource sharing.
- An implementation of the SMB and Active Directory protocols for Linux and UNIX-like systems.




Installation de Samba

- In 1992, **Andrew Tridgell** developed a sharing protocol for Unix.
- Compatible with Microsoft SMB.
- Named Samba. (SaMBa).
- Distributed under the GNU/Linux licence from 1997 onwards.




Installation de Samba

- Samba combines several protocols:
- NetBIOS over TCP/IP:
- CIFS: (Common Internet File System) now called SMB2.
- Wins (Windows Internet Name Service).




Composantes de Samba

- Samba combines several protocols:
- NetBIOS over TCP/IP:
- CIFS: (Common Internet File System) now called SMB2.
- Wins (Windows Internet Name Service).




Composantes de Samba

- **nmbd**: The daemon understands and responds to NetBIOS name service requests.
- Plays a role in the browsing protocols that make up the Windows network neighbourhood display.
- Operates on port 137.
- It is controlled by the nmb service.




Composantes de Samba

- **winbind**: The service resolves information about users and groups on a Windows NT server and makes it usable by UNIX platforms.
- Uses the RPC protocol.
- Controlled by the smb service.




Installation of Samba

- Update system:
- `apt update && sudo apt upgrade -y`
- Install Samba:
- `apt install samba -y`
- Verify:
- `smbd --version Or systemctl status smbd`



Samba configuration

- **/etc/samba/smb.conf**
- Composed of several sections :
- Defining the different types of sharing.
- Files.
- Printers.
- Sharing modes.
- Actions permitted on shares.



Samba configuration

```
#===== Global configuration =====


[global]

workgroup = The_Work_Group
security = Security_mode
map to guest = <Action with Invalid count>

#== Share =====

[Share]

path = Path_of_Shared_Dir
Browsable=<yes or no>
writable = <yes or no>
guest ok = <guest user allowed yes or no>
read only = <yes ot no>
```




Samba configuration

- **Workgroup**: workgroup of windows users.

With cmd or in control panel :


```
C:\> net config workstation
```

- **security** : Determines the security mode used for sharing it can be:
- **share** : sharing is performed without any security.
- **user** : access is subject to authentication by Samba account.
- **Domain** : authentication is performed by a domain name.



Samba configuration

- **map to guest**: Determines the action to be taken in the event of invalid authentication:
 - **never**: login with an invalid account is rejected (default).
 - **bad user**: it will be treated as a guest account.
- **path** : Define the shared directory /share
- **browsable** : Client can browse the shared directory.
- **writable** : Write allowed.
- **guest ok** : if yes no password is needed.
- **read only** : yes or no.



Samba configuration

```
#===== Global configuration =====


[global]

workgroup = WORKGROUP
security = share
map to guest = bad user

#== Définition du partage =====

[Partage]

path = /myshare
browsable =yes
writable = yes
guest ok = yes
read only = no
```



Samba configuration


- Restart samba service:

```
Systemctl restart smbd
```

- Create a user for example **smbuser** and activates it for samba service by command:

```
smbpasswd -a smbuser
```






Samba configuration

- To test the samba service, we can use the host machine as a client. In this case use host only mode.
- In file browser in the client : \\IP_Samba_Server\\





Samba configuration


- To test the samba service (use host only mode).
- We can mount the shared directory on client machine by cmd command:

```
net use z: \\ServIP\ShareDirectory
```

- For example

```
net use z: \\192.168.56.150\Share
```

```
C:\Users\akram>net use z: \\192.168.56.150\share  
The command completed successfully.
```



Samba configuration

- To show the shared directories, use: **net use**

```
C:\Users\akram>net use  
New connections will be remembered.
```

| Status | Local | Remote | Network |
|-------------------------------------|-------|--------------------------|---------------------------|
| <hr/> | | | |
| OK | Z: | \\"192.168.56.150\\share | Microsoft Windows Network |
| The command completed successfully. | | | |

- To **unmount** the shared drive (z:) use
- **net use * /delete**